



6320 E Stassney Ln. Phone / 1.800.615.8350
Austin, TX 78744 Email / sales@feniex.com



Quantum Software

How to Upgrade to Dual, Tri or Quad

In this video I plan to show you as a distributor how to upgrade your bar and unlock it from a single color state to a dual, tri or quad. So we touched on this section in video one. What it means is that you can enter in the PUID remotely or scan it based on the QR code to be able to upgrade your light bar from a single color state to a dual, tri or quad. But for this video I plan to plug in the bar and show you how to do the exact same thing while your bar is plugged into your PC. As you can see, the exact same screen appears. The only difference is that in this case, the bar is plugged into your PC. Programming it and upgrading it in this state will allow me to show you what the configurator will output based on what the unlocked level type is. Upgrading your light bar from a single color state to a dual, tri or quad is really simple to do. It only takes 30 seconds. In this case, the bar is programmed in a single color state, so the configurator outputs a single color configuration. When clicking the tab to upgrade to dual color, a pop-up window will appear displaying your total price, the dealer cost of the upgrade, not the retail price of the upgrade. Your discount levels automatically already calculated. You can simply select the payment type and click submit. Within seconds your bar is now upgraded to the dual color type and when I click configurator I have the dual color configurator available. I can also choose to upgrade my bar from a dual to tri. The same process applies. I simply click the unlock tri color. A pop-up window appears and my pricing of \$78 to upgrade from dual to tri is available. I select my payment type and click submit. My bar is now programmed in less than a few seconds and my tri color configurator is now available. Same process applies for quad. A pop-up window will appear. \$78 to upgrade it based on my five-star level pricing. I'll click submit payment, my bar is upgraded, and the configurator of quad appears. Upgrading your bar from single to dual, tri or quad only takes a matter of seconds to do, and this feature is only available for distributors. That concludes this video of how to upgrade your light bar from single to dual, tri or quad.