

FUSION-S

BRIGHT MADE BRIGHTER

FUSION® LICENSE PLATE MOUNT

FLP-26



Specifications ▲
pp. 03

Wiring Guide ▲
pp.03

Patterns & Modes ▲
pp.03



Fenix Product Copyrights This price list and the mentioned Fenix products include or describe copyrighted Fenix material. Laws in the United States and other countries preserve for Fenix Industries and its licensors certain exclusive rights for copyrighted material, including the exclusive right to copy, reproduce in any form, distribute and make derivative works of the copyrighted material. Accordingly, any copyrighted material of Fenix and its licensors contained herein or in the Fenix products described in this Price List may not be copied, reproduced, distributed, merged or modified, transmitted, transcribed, stored in retrieval system or translated into any language or computer language, in any form or by any means, without prior written permission of Fenix Industries, Inc. Fenix and the stylized Fenix logo are registered in the U.S. Patent & Trademark Office.



SAFETY REGULATIONS & WARRANTY

Safety Regulations

The following provides all the information necessary to safely operate the previously listed products of Fenix Industries, Inc. Please read this manual thoroughly before installing or operating your new product in order to prevent any damage or injury. Failure to follow the listed instructions in this manual may result in damage to your products or personal injury.

- Proper installation of this product requires good knowledge of automotive systems, electronics and procedures.
- Please guarantee all vital components of the vehicle are not in danger of being damaged by drilling holes necessary for installation. Check all sides of the mounting surface before drilling any holes into the vehicle.
- Do not install this product in any way that interferes with the deployment of the air bag. Doing so may damage the effectiveness of the air bag and can lead to serious personal and vehicle injury. The installer will assume full responsibility of proper installation of the new unit.
- Please clean the mounting surface before installation of the unit when using tape, brackets, magnet, Velcro or suction cups.
- The product's ground wire must be connected directly to the Negative (-) battery post for effective use of the unit. Please follow all wiring guidelines provided to guarantee long lifespan and productivity. Failing to follow these instructions may result in damage to the product.

Warranty

Fenix Industries, Inc. warrants to the original purchaser that all our products shall be free from defects in material and workmanship. Fenix Industries' speakers, sirens, rocker panels, AM600 Beacons, Torch Lights, Al lightbars, Al Cubes, AM900 Work Lights, 8.5" Dome Lights, Cargo Lights, flashlights, Remote Spot Lights, and controllers are warranted for 2 years from the manufacturing date. In addition, all other products are warranted for 5 years from the manufacturing date.

If a warranty problem occurs, please contact customer support at 1.800.615.8350 or visit the website at www.fenix.com/support.

If the product needs to be returned for repair or replacement, call our customer support line to receive a return merchandise authorization number.

Operational times are from 9 a.m. to 6 p.m. central time, Monday through Friday. Please do not send in product without contacting support first for an RMA number.

Service After Expiration

Fenix Industries will still provide service for all products after the expiration of the warranty. In some instances it may be necessary for the product to be shipped, freight prepaid, and insured for loss or damage to Fenix headquarters.

Warning! Utilizing non-factory screws and mounting brackets may result in loss of warranty coverage.

Copyright

This instruction manual and the Fenix products described in this instruction manual may include or describe copyrighted Fenix material. Laws in the United States and other countries preserve for Fenix Industries and its licensors certain exclusive rights for copyrighted material, including the exclusive right to copy, reproduce in any form, distribute, and make derivative works of the copyrighted material. Accordingly, any copyrighted material of Fenix and its licensors contained herein or in the Fenix products described in this instruction manual may not be copied, reproduced, distributed, merged, or modified in any manner without the express written permission of Fenix Industries, Inc.

Fenix Product Copyrights

The products described in this document are the property of Fenix Industries, Inc. It is furnished by express license agreement only and may be used only in accordance with the terms of such an agreement. Products and documentation are copyrighted materials. Making unauthorized copies is prohibited by law. No part of the product or documentation may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, without prior permission from Fenix Industries, Inc.



BOX CONTENTS

1x - License Plate Mount Cover

2x - Fusion-S Light Modules

Mounting Screws

WIRING GUIDE



3 input wire harness
with Ground wire and 1
pattern wire

FLASH PATTERNS

■ Syncing Flash Patterns

1. Connect the blue sync wire(s) of the product(s) you would like to sync.
2. Hold the blue sync wire to 12V Ground for 3 seconds. The flash pattern will reset to "single-slow."
3. Momentarily tap the blue wire to 12V Ground to cycle the flash patterns.

■ Alternating Flash Patterns

1. Connect the blue sync wire(s) of the product(s) you would like to sync.
2. Hold the blue sync wire to 12V Ground for 3 seconds. The light(s) will turn steady on for follower and no lights for leader.

SPECIFICATIONS

DIMENSIONS 13.30" x 6.31" x 0.98"

VOLTAGE 10-18VDC

CURRENT 2 Amps @ 13V

WARRANTY 5 Years

WIRE INPUT

Red 12V+, Input 1

Yellow 12V+, Input 2

White 12V+, Input 3

Green N/A

Blue Ground, Sync/Pattern

Black Ground

1 Single Slow

2 Single Fast

3 Single Combo

4 Dual Slow

5 Dual Fast

6 Dual Combo

7 Triple Slow

8 Triple Fast

9 Triple Combo

10 Attack 1

11 Attack 2

12 Brake Pop

13 Tail 10%

14 Steady On 100%