



6320 E Stassney Ln. Phone / 1.800.615.8350
Austin, TX 78744 Email / sales@feniex.com



Quantum Software

How to Program Arrow Mode

In this video, I'll show you how to program directional mode using tri-color as the example. As you can see in my tri-color configuration, I have amber located in the rear. I'll start off by selecting an input, then directional mode, and then I'll click the module that I wish to activate. In this case, I'm given the choice of the three colors that I programmed in the previous step, so I'll select amber in every single spot. Once done, I can apply the text left, and then the pattern, left fast for example, and the brightness level, most likely 100%. I can then do the same thing for a right pattern. Select an input, right as my text, choose the arrow directional, and then simply select all the modules that I wish to illuminate on this pattern. Once done, select the right flash pattern, my brightness level and I'm set. Don't forget to program your bar. And don't forget you also have a center out pattern to select from if you wish to. That concludes how to program arrow mode using the quantum configurator.